

## CUSTOMER RELEASE NOTES

### *Enterasys RoamAbout® GuestPass Application Firmware Version 6.0.1.1 September 18, 2007*

#### INTRODUCTION:

The RoamAbout GuestPass Application enables non-IT staff to configure temporary user accounts for guest access to the network. The guest account administrator can use GuestPass to quickly and easily create guest user accounts and deploy the account information to RoamAbout switches in the network.

**Enterasys recommends that you thoroughly review this document prior to installing or upgrading this product.**

#### FIRMWARE SPECIFICATION:

Status	Version No.	Type	Release Date
Current Release	6.0.1.1	Customer	September 2007
Previous Release	5.0.1.1	Customer	December 2006
Previous Release	4.2.2.1	Customer	September 2006
Previous Release	4.1.4.0	Customer	May 2006
Initial Release	4.1.2.0	Customer	November 2005

#### HARDWARE COMPATIBILITY:

RBT-8x00

#### SYSTEM REQUIREMENTS:

Hardware requirements for running the GuestPass Application on Windows systems:

	Minimum
Operating System	Microsoft Windows XP with Service Pack 1 or higher
Processor	Intel Pentium 4 2 GHz or equivalent
RAM	256 MB
Hard drive space available	100 MB
Monitor resolution	1024x768 pixels, 24-bit color

#### SUPPORTED FUNCTIONALITY:

AAA – this includes the creation of guest user accounts for the local authentication database, provided there are preconfigured Guest Network access rules. The administrator can add users and deploy the information to the RoamAbout Switches.

## CUSTOMER RELEASE NOTES

### INSTALLATION AND CONFIGURATION NOTES:

Please refer to the *GuestPass User's Guide* for complete installation instructions, located on the Enterasys Web site <http://www.enterasys.com/products/wireless/>.

Download the firmware from the Enterasys Wireless Download page, and install it on your PC.

### FIRMWARE CHANGES AND ENHANCEMENTS:

#### Firmware Release 6.0.1.1:

- Added support for interaction with the 6.0.x.x RoamAbout Switch firmware.

#### Firmware Release 5.0.1.1:

- Added support for interaction with the 5.0.x.x RoamAbout Switch firmware.

#### Firmware Release 4.2.2.1:

- Added support for interaction with the 4.2.4.1 RoamAbout Switch firmware.

#### Firmware Release 4.1.4.0:

- Resolved two GUI issues, one with resizing the About window, one with the Help file title display.
- Resolved an issue where the application would attempt a RAS upload with a previously entered incorrect IP address.
- Resolved an issue where the application would attempt a RAS upload with a previously entered incorrect password.

Please check our web site on a regular basis for updates at <http://www.enterasys.com/products/wireless/>.

### KNOWN RESTRICTIONS AND LIMITATIONS:

#### Firmware Release 6.0.1.1:

- The changes from the GuestPass application have to be manually accepted into the RoamAbout Switch Manager (RASM) application database.

For the most up-to-date information concerning known issues, go to the **Global Knowledgebase** section at <http://www.enterasys.com/support/>. To report an issue not listed in this document or in the **Global Knowledgebase**, contact our Technical Support Staff.

### GLOBAL SUPPORT:

By Phone: 978-684-1000  
1-800-872-8440 (toll-free in U.S. and Canada)

For the Enterasys Networks Support toll-free number in your country:  
<http://www.enterasys.com/services/support/contact/>

By Email: [support@enterasys.com](mailto:support@enterasys.com)

By Web: <http://www.enterasys.com/support/>

By Fax: 978-684-1499

By Mail: Enterasys Networks, Inc.  
50 Minuteman Road  
Andover, MA 01810 (USA)

For information regarding the latest software available, recent release note revisions, or if you require additional assistance, please visit the Enterasys Networks Support web site.